

MED-PAT®




AVAZA Language Services introduces the MEDPAT D2200– Dual Handset Phone for interpreting. As the only FCC compliant phone in the industry, it offers, clarity, security, and user-friendly features.

The 2 Can Talk 2™ Telephone -MEDPAT D2200 is an analog phone (RJ11) that can be conveniently placed in examination rooms and lobby areas.

Deluxe Euro Style 2 Handset Telephone
Designed for Interpretation.

- It has MICROBLOCK Antibacterial Surface Protection for infection control
- 3 Built in Memory Keys
- Patented **Volume Plus Button** designed with features for the hearing impaired aiding 70% of elderly patients with high-frequency hearing loss (the Boost Button increases volume range to 27.5db)



- Built in CLEARING AID® circuitry automatically adjusts frequency response for improved clarity. This is an aid to 70% of Patients with high-frequency hearing loss.
- Designed with twin handsets the 2 Can Talk 2™ telephone ensures privacy during conference calls, in-house interpreting, or while using a language interpretation service. Each user has a separate handset for confidential communication.
- Perfect in Labor and Delivery Rooms to allow both parents to simultaneously be on the phone.
- Clear Ear Sound
- Easy to wipe down, sleek profile, Lite Touch Keypad with  No Wear / Non Rub Off keys
- Flash Button
- Free Faceplate Customization
- High Luster, Euro Style, Rugged ABS cabinet with High Durability Components
- Extra Long Fully Modular Cords
- Rotary Handset Volume Control plus additional Volume Plus Button on Base
- Very Large Faceplate Area

- ABS cabinet. Total Telephone weight 2.5lbs.
- Built in speakerphone with automatic differential balancing; >80 dB receive to transmit.
- Extra Heavy, Non-Slip Base provides a solid look and feel
- One Year Warranty
- Three Memory Buttons with Non-Volatile Permanent Memory. No Battery Needed.
- Two Headset Connections with Separate Volume Controls.
- “Super Bright” Ringer/Message Indicator Light

OPERATING INSTRUCTIONS



PLACING A CALL

Pick up the left handset, or press the **SPEAKERPHONE** button and dial the number or programmable Speed Dial button.

RECEIVING A CALL

When the phone rings, either pick up the left handset, or press the **SPEAKERPHONE** button to answer the call.

DUAL-HEADSET READY

To use two headsets simultaneously, plug one into the left jack and one into the right jack. To make a call, press the **HEADSET ON-OFF** button and dial the number. To use one headset and one handset, plug the headset into either side and hang up the handset on that same side.

- To make a call when the headset is plugged into the right side, pick up the left handset and dial the number.
- To make a call when the headset is plugged into the left side, push the **HEADSET ON-OFF** button and dial the number.

USING THE SPEAKERPHONE

For a hands-free conversation, press the **SPEAKERPHONE** button and dial the number. The speakerphone volume is controlled by the left handset volume control.

- To switch from the handset to the speakerphone, press the **SPEAKERPHONE** button before you hang up the handset.
- To switch from the speakerphone to the handset, simply pick up the handset.
- To switch from the speakerphone to the headset, press the **HEADSET ON-OFF** button.

SPEED DIAL

To use speed dial, press the **MEMORY** button for the number you want; the speakerphone will automatically come on (if you have not already picked up the left handset) and the preprogrammed number will dial out.

VOLUME ADJUSTMENT

Use the volume control located on each handset to adjust that handset's (and associated headset's) volume from normal to loud.

VOLUME+ FEATURE

Press the **VOL+** button to increase the receive volume on both the handsets and headsets from loud to very loud. The volume will reset to normal when the phone is hung up.

MUTE BUTTON

Press the **MUTE** button once to turn on the mute function and press the **MUTE** button again to turn off the mute function.

FLASH BUTTON

Press the **FLASH** button to disconnect the phone and automatically acquire a dial tone. This is most often used to end a call and immediately dial another number or for call waiting purposes.

EXTRA-LONG HANDSET CORDS

The left handset has a 7' cord for. The right handset has a 9' cord, allowing the patient to use the phone from an extended distance.

PROGRAMMING A SPEED DIAL NUMBER

1. Pick up the left handset to activate the phone.
2. Press the **PROGRAM** button using a small paperclip.
3. Dial the desired number.

4. Press the **PROGRAM** button again.
 5. Press the desired **MEMORY** button.
 6. Hang up the handset.
- Repeat steps 1-6 for each **MEMORY** button.

REPLACING YOUR MEDPAT D2200 DUAL HANDSET PHONE

If you have a broken or defective phone and you need a replacement, please call Customer Support at 800-482-8292 to place a new exchange order.